


TOP AND CONSOLE PARTS

For Model: WGD5300SQ0, WGD5300ST0 (Designer White) (Biscuit)

Illus No.		DESCRIPTION	Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION
1		Literature Parts	6	8274261	Panel, Rear	23	3403498	Connector,
	8562582	Installation			Console			3-Position
		Instructions	7	3395683	Housing, Connector			(Gas Valve)
	W10042960	Sheet,			(Motor)	29	8533971	Screw, 8-18 x 5/16
		Cycle Feature	8		Cap, End (R.H.)	30		Nut, Push-In (2)
	8578183	Use & Care Guide		8271359	White	31	8299876	Harness, Wiring
	8528187	Wiring Diagram		8271362	Biscuit	32	3977456	Switch,
			10		Screen, Lint			Push-To-Start
Following May Be Purchased				8557857	White	33		Timer Knob
_	O IT VOI	IDSEL E		8557858	Biscuit			Assembly
	OO-IT-YOU		11	8536939	Clip, Spring		8566061	White
F	REPAIR MA	ANUALS	13		Screw, 8-18 x 5/8		8566064	Biscuit
_			15		Screw, Hex Head	34	717252	Receptacle,
	677818	Dryer	16		Тор			2–Way
				8557930		35	94614	Terminal
2	8533951	Screw, Grounding		8557931	Biscuit	36	8544895	Bracket, Control
3	3394427		20		Knob, Control	37		Panel, Control
4		Cap, End (L.H.)		8566065			8578844	White
	8271365	White		8566068			8579482	Biscuit
	8271368	Biscuit	21		Timer Assembly	38	3936144	Connector
5	3397269	Connector	-		(60 Hz.)	39	388326	Screw, Console
		(Timer)	22	3403499				,
				2.23.33	2–Position			
					(Gas Valve)			

CABINET PARTS



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST


CABINET PARTS

For Model: WGD5300SQ0, WGD5300ST0 (Designer White) (Biscuit)

Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION
1	697776	Screw, 10-32 x 5/8	18		Cabinet	37		Handle, Door
		(External Ground)			(Includes		8566059	
2		Screw, 10-16 x 1/2			Illus. 8)		8566071	
3	3404162	Clamp, Motor		8530603		38	3406129	Seal & Bearing
		(W/Shield)		8530606				Assembly
4		Plug,	19	98234	- 1 / (/	45	344020	Cord, Power
		Strike Door	20	690363	Lock, Front Top (2)	49		Plug, Front Panel
	3403630		21		Panel Front		3394975	
	3403632			3403447			3394978	
5	3396795	Cover, Block		8282482		51		Hinge, Top (2)
6	693995	Screw, Hex	23	685203	Clip, Felt Pad (2)	53	691366	Idler & Pulley
		Washer Head	24	3389441	Catch, Door			Assembly
7	3396805	Panel, Rear			Assembly	56		Belt, Drive
8	8541400	Bracket, Cabinet	25	3405246	Seal, Door	57	348780	Base, Motor
9	3980175	Clamp, Elbow	27	342055	Screw, 8-18 x 1/2	58		Bolt, 5/16–18 x 3/4
10	3406109	Door Switch	28	3405514	Hinge, Door	59		Pulley, 60 Hz.
		Assembly	29	3394083	Clip, Front	62	8066206	Motor Assembly
11	697773	Screw, 6-20 x 7/8			Panel			60 Hz.
14		Plug,	33	3403431	Strike, Panel	63		Clamp, Motor
		Hinge Hole	35	3402341	Door, Rear	67	8318272	Burner Assembly,
	3404413	White	36		Door, Front			60 Hz.
	3404415	Biscuit		3402335	White			(See Pages 7 & 8
16	3392100	Foot, Dryer		3402337	Biscuit			For Further
	279810	Foot – Optional						Burner Breakdown)
		(Extended Length				68	341029	Clamp, Pipe
		Package Of 2						
		(Not Included)	l					

BULKHEAD PARTS

For Model: WGD5300SQ0, WGD5300ST0 (Designer White) (Biscuit)



BULKHEAD PARTS

For Model: WGD5300SQ0, WGD5300ST0 (Designer White) (Biscuit)

Illus. No.	Part No.	DESCRIPTION
1	348368	Lint Chute Assembly
2 3 4	489463 3388703 347139	Screw, 8-18 x 5/8
5 6 7 8	90767 3406022 3392519 8066086	
9	3387134	Thermostat, Internal-Bias
10	694089	Wheel, Blower (Includes Illus. 21)
11 12 13 14 15	8577230 8066155 343641 8530285 3403140	Housing, Blower Clip Screw, 10–16 x 1/2 Box, Heater Thermostat, 205°F (96°C)
18 19 24	8066049 3390647 280010	Funnel, Burner Screw, 8–18 x 1/2 Kit, Thermal Cut–Off (Includes
25 41 42 43 44 46 47 48 49 62 63 66 67 68 69 70 71 73 75	3401707 690997 3399506 3399507 3397590 348197 3359452 3403491 338906 692526 97787 3406130 695587 692490 3976434 90296 3403636 339956 696302	Illus. 15) Wire, Jumper Ring, Tri Shaft, L.H. Shaft, R.H. Roller, Support Washer, Support Nut, 3/8–16 Bulkhead Sensor, Radiant Ring, Bearing Screw, 11–16 x 3/4 Seal, Rear Drum Drum Assembly Baffle, Drum (2) Bracket, Support Clip Baffle, Drum (1) Seal Shield, Exhaust

8318272 BURNER ASSEMBLY

For Model: WGD5300SQ0, WGD5300ST0 (Designer White) (Biscuit)

USE WITH TYPE 1 - NATURAL

AND TYPE 4 LIQUEFIED PROPANE AND BUTANE GASES BA-150 - 6

8318272 BURNER ASSEMBLY

For Model: WGD5300SQ0, WGD5300ST0 (Designer White) (Biscuit)

USE WITH TYPE 1 – NATURAL AND TYPE 4 LIQUEFIED PROPANE AND BUTANE GASES

Illus.	Part	
No.	No.	DESCRIPTION
1	8318272	Burner Assembly 60 Hz. (Type 1) (White Rodgers)
2	688617	Tube, Burner
2 3 4 5	694298	Bracket, Ignitor
4	686590	Ignitor
5	3393909	Screw & Washer (8-32 x 5/8)
6	343641	Screw, 10-16 x 1/2
7	693986	
8 9	3387057	Screw, 8–18 x 3/8
9	00.4000	Orifice, Burner
	234826	
	229742	
10	234868 8318277	Type 4 (Propane) Valve, 60 Hz.
10	0310211	(Includes Pipe &
		Illus. #7)
11	694421	Screw,
• • •	001121	8–32 x 1/2 (2)
12	694538	Bracket, Coil
13	694540	Coil, 60 Hz.
		(2 Terminal)
		(Main)
14	694539	Coil, 60 Hz.
		(Split)
		(3 Terminal)
	004404	(Pilot Position)
15	694424	
16	694423	
17	694422	Adjustment
20	239822	Spring, Regulator Plug, Pipe
25	341029	Clamp, Pipe
20	011020	Ciamp, ripo

Following Parts Not Illustrated

694572 Conversion Kit (Type 1) to Type (4) L.P.G.

BA-150

OPTIONAL PARTS (NOT INCLUDED)

For Model: WGD5300SQ0, WGD5300ST0 (Designer White) (Biscuit)

Illus. Part

No. No. DESCRIPTION

ACCESSORY PARTS

279948 Kit,

Dryer Repair

346764 Kit, Hold-Down

(Gas Dryer Mobile

Home Installation)

3404351 Dry Rack

8522199 Kit, Dryer

Vent Testing

PAINT, TOUCH-UP (1/2oz.)

72017 White

4392899 Biscuit

PAINT, PRESSURIZED SPRAY

(12 oz.)

350930 White

4392901 Biscuit

350938 Primer, Gray

PAINT, BULK (1 qt.)

799344 White (Uncut)